WARNING: This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electric shock or fire, which could cause serious bodily injury.

For household us Only
Important safeguards

When using electrical appliances, basic safety precautions should always be followed including the following:

1. **Read all instructions.**
2. To protect against electrical hazards, **DO NOT** immerse cord, plug or appliance in water or other liquid.
3. **Close supervision is necessary** when used by or near children.
4. **ALWAYS** unplug from outlet when not in use.
5. **DO NOT** operate any electrical appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any manner. **RETURN** all malfunctioning appliances to the factory for examination.
6. **DO NOT** use appliance for other than its intended use.
7. **DO NOT PUNCTURE HEATER FOR ANY REASON.**
8. For use with 110-120 volt AC **ONLY.**
9. **CORD MUST EXIT** towards the back of bed, away from normal travel of pet.
10. A liner must separate the pet bed warmer from the stuffing material.
11. When using this product, make sure your pet has the option of sleeping on or OFF the bed.
12. **SAVE THESE INSTRUCTIONS FOR YOUR USE.**

Instructions

1. Carefully position heating pad between foam pieces and close the opening so your pet cannot remove the heating pad. When in use, check the pad to ensure proper positioning.
2. Turn the bed so the cord is exiting the back of the bed, away from the normal path traveled by your pet.
3. When cleaning the bedding, unplug and remove the heater so you do not subject it to being immersed in liquids or cleaners.
4. Remove cover for washing.
5. Follow the above instructions when reassembling you **THERMO-KITTY FASHION SPLASH**.
6. ALWAYS give your pet the choice to lie on OR off the heated bed.

Testing your new THERMO-KITTY FASHION SPLASH.
After operating about 1 hour place a pillow over your beds sleeping surface for 20-30 minutes. Then place your hand under the pillow to feel the warmth your per will feel when using the Thermo-Kitty Fashion Splash.

MODE D'EMPLOI

1. Placer l'unité chauffante entre les deux morceaux de mousse isolante et fermer l'ouverture afin que votre animal ne puisse pas sortir l'unité chauffante. S'assurer régulièrement que celle-ci est bien installée.
2. Placer le panier de façon à ce que le cordon d'alimentation sorte à l'arrière et n'interfère pas avec les déplacements de l'animal.
3. Lors du nettoyage du panier, débrancher l'unité chauffante et sortez-la pour ne pas la mouiller ou répandre des produits d'entretien dessus.
4. Enlever la housse pour la nettoyer.
5. Suivre les indications susmentionnées lors de la remise de l'unité chauffante dans la housse.

Essai du nouveau THERMO-KITTY FASHION SPLASH

Après avoir opréré durant 1 ou 2 heures, placer vos mains sur le nouveau THERMO-KITTY FASHION SPLASH de votre animal et appuyer durant 30 secondes. La meilleure façon de sentir la chaleur dégagée par THERMO-KITTY FASHION SPLASH est de s'asseoir dessus pour constater que l'animal sera bien au chaud. Pour la sécurité et le plaisir de votre animal de compagnie THERMO-KITTY FASHION SPLASH est conçu pour dégager une tiédeur radiante agréable. IL NE DEVIENT JAMAIS CHAUD!